

City Car Operation sheet

Material- Poplar, close grain pine or equivalent.

Equipment required. Band saw, Drill press, Router & sandpaper.

Finish-None required-Leave as bare wood.

Other material.-Commercial 1" wheels & axles.

Operations:

1. Cut wood to size 3 1/2:"L x 2" H x 1 1/2" W. Using template trace outline of car on work piece.
2. Drill axle holes through. Drill size 7/32"
3. Drill window hole through . Drill size 3/4".
4. Cut out profile of the car.
5. Sand all sharp edges or round over with a 1/8" router bit.
6. Assemble axle and wheels.If wood is 1 1/2"or narrower you may have to shorten two axles. Check before the glue assembly
7. Stand back and admire your craftsmanship.

